



REVISION:			
G	11/28/2017	UPDATES	ECF




STEP 1:
 REMOVE TILE AND IDENTIFY
 RAFTER LOCATION WITH A
 PILOT DRILL. MOUNT STANDOFF
 ASSEMBLY TO ROOF SHEATHING
 WITH A 5/16"Ø LAG SCREW
 MINIMUM 2 1/2" EMBEDMENT TYP.
 BE SURE LAG SCREW IS FULLY SEATED



STEP 2:
 SLIDE FLASHING OVER POST,
 UNDER UPPER LAYER OF TILE

* PRIMARY WATERPROOFING ON A
 TILE ROOF OCCURS AT THE ROOF
 FELT. THE ADJACENT TILES ABOVE
 AND TO THE SIDES OF THE ROOF
 ATTACHMENT MUST CONCEAL THE
 EDGES OF THE ROOF FLASHING.
 CUTTING AND REPLACING THE TILE
 IS RECOMMENDED BUT NOT
 REQUIRED FOR ADEQUATE
 WATERPROOFING.

STEP 3:
 USE CORING BIT OR OTHER METHOD TO DRILL 2 1/2"Ø CLEARANCE
 HOLE IN TILE TO ALLOW TILE TO BE REPLACED IN ORIGINAL LOCATION *



STEP 4:
 REPLACE TILES
 SEAL TOP OF CONE FLASHING WITH
 RUBBER RAIN COLLAR, ALUMINUM
 TAPE, OR ALTERNATIVE METHOD

