

STEP 1:  
 DRILL  $\frac{3}{16}$ " Ø PILOT HOLE IN RAFTER.  
 ENSURE AREA SURROUNDING HOLE IS  
 FREE FROM METAL SHAVINGS AND  
 DEBRIS.

STEP 2:  
 ATTACH METAL ROOF BASE TO  
 RAFTER WITH  $\frac{5}{16}$ " Ø LAG SCREW.  
 TORQUE TO 10-16 FT LBS.

STEP 3:  
 THREAD METAL ROOF BASE CAP ONTO  
 METAL ROOF BASE BOTTOM. TAKE  
 CARE TO ENSURE THE BASE DOES  
 NOT TWIST WHEN CAP IS TIGHTENED.  
 ENSURE CAP IS FULLY SEATED TO  
 BASE.

STEP 4:  
 ATTACH L-FOOT TO STUD IN METAL  
 ROOF BASE CAP WITH FLANGE NUT.

REVISION:		
G	11/28/2017	DR

